

Mått — nätdörr

Mät öppningen där nätdörren ska sitta. Bredd först, sedan höjd.

01

Mått

Mät karmens innerkant, minsta måttet om det varierar. Ange hängning — höger eller vänster sett utifrån.

When the door hinges are placed on a wall, it is necessary to determine the width of the door, it is necessary to evaluate these parameters and leave enough

- **Mesh door height** – the distance from the top or the upper profile of the frame to the bottom of the bottom profile. Add 20 - 80 mm to the height of the opening so that the mesh - door closes tightly, depending on the specifics of the place. Measure the height of the opening in several places.
- **Color of construction** – white, brown (RAL 8017), anthracite, imitation of dark wood (walnut), imitation of light wood (golden oak)
- **Type of mesh** – standard or antiallergic
- **Pet door** – you can choose from two sizes. 200 mm x 250 mm or 300 mm x 400 mm. If the product is ordered with a shield, the distance from the bottom of the mesh door to the bottom of the pet door will be 100 mm. If the product is ordered without a shield, the distance from the bottom of the mesh door to the bottom of the pet door will be 50 mm.

